

*Parkland Heritage*©

**ASSEMBLY AND OPERATING  
INSTRUCTIONS**

Produced Exclusively by D.C.America

(Fits Model GONSW84188 10' x10' WEATHER WICKER GAZEBO)



CORPORATE OFFICE:

P.O.BOX 660999 Arcadia, CA91006

1-800-238-LAWN(5296)

Monday thru Friday, 8:30 AM to 4:30 PM, PST

*Parkland Heritage*©

is a trademark of D.C.America. All rights reserved.

## **Read Manual**


Your Gazebo requires assembly prior to use. It is important that you read the entire manual and become familiar with the unit BEFORE you set up the Gazebo.














## **Safety Warning and Precautions**


**WARNING:** When using product, basic safety precautions should always be followed to reduce the risk of personal injury and damage to equipment.

Read all instructions before assembling and using this product.

1. **Select ideal location.** Set out all parts on a clear and level surface prior to assembly. Ideally, the Gazebo should be set up in the desired location to avoid moving it after assembly.
2. **Use caution.** During the assembly process, especially when lifting heavy or large parts, pay attention to safety. Only those assembling the product should be allowed in the work area.
3. **Tools and Assistance.** Ladder and wrench are self-provided. Whenever possible, assistance is preferred.
4. **Check for parts available.** Before assembling your Gazebo, make sure that you have all parts described in the Parts List on page 3.
5. **Check for damaged parts.** Before assembling your Gazebo, check for damaged parts. Any part that appears damaged should be carefully checked to determine if it can operate properly and perform its intended function. Any part that is damaged should be properly repaired or replaced by a qualified technician.
6. **Refer to assembly diagram.** During assembly, it is helpful to refer to the assembly diagrams provided.
7. **Keep children away.** Children should be kept away from the work area. Do not allow children to handle any parts or tools. No one other than the assemblers shall be allowed in the work area.
8. **Please keep this Assembly Instruction for future use.**




A		4PCS
B		4PCS
C		4PCS
D		4PCS
E		1PC
F		16PCS
G		1PC
H		1PC
I		8PCS
J		8PCS
K		16PCS
L		16PCS
M		1PCS



- ④ Attach the top tube(D) to center connector(E).
- ⑤ Insert top tube(D) to screen(A).

- ① Attach the screen(A) to screen(B) with fixtures(F)
- ② Attach the lintel(C) to screen(A/B) with fixtures(F)
- ③ Attach side sliding(J) to screen(A/B) and lintel ( C ) with nuts and bolts(K+L).



- ⑥ Cover the frame of the gazebo using fabric(G), then secure by pulling fabric onto the ends of (D) top tubes.
  - ⑦ Hang the mosquito netting(H) onto side railing(J) with velcro
  - ⑧ Adjust the position of the gazebo, secure to ground by inserting stake(I) into the holes of posts.
- Now your gazebo is ready for use!